

Custom All Aluminum Stacker Trailers

BUILT FOR SPEED

High Quality Trailers Built by Racers for Racers

SEMI, GOOSENECK, FIFTH WHEEL AND PULL-A-LONG TRAILERS

UNRUH RACING - STACKER TRAILER



Call for a Quote - 815.426.2761

www.tande-racetrailers.com













Custom Built Trailers for
T&E ENT.
AutoHaulers
ESTABLISHED 1974

STI








CAUTION
HIGH VOLTAGE
ELECTRICAL
EQUIPMENT
DO NOT TOUCH
UNLESS YOU ARE
A QUALIFIED
ELECTRICIAN
OR A LICENSED
ELECTRICIAN
SEE THE OWNER'S
MANUAL FOR
SAFETY INSTRUCTIONS

GENERATOR SPECIFICATIONS

MODEL	OUTPUT	TYPE
PT-1000	1000W	INVERTER
PT-2000	2000W	INVERTER
PT-3000	3000W	INVERTER
PT-4000	4000W	INVERTER
PT-5000	5000W	INVERTER
PT-6000	6000W	INVERTER
PT-8000	8000W	INVERTER
PT-10000	10000W	INVERTER
PT-15000	15000W	INVERTER
PT-20000	20000W	INVERTER
PT-30000	30000W	INVERTER
PT-40000	40000W	INVERTER
PT-50000	50000W	INVERTER
PT-60000	60000W	INVERTER
PT-80000	80000W	INVERTER
PT-100000	100000W	INVERTER

GENERATOR SPECIFICATIONS



Small text on the right side of the panel, likely a warning or instruction label.



AIR RIDE

13.31

ON

TRAILER

METER

AIR PUMP

COMPRESSOR

TRAILER

TRAILER

ASTAR

ALL ACTIVITIES
www.astarusa.com
MADE IN THE USA









WX STATION PORTS WITH POLE MOUNT BETWEEN...







Custom Built Trailers by...

T & E ENT.
AutoHaulers

HERSCHER, IL.
815-426-2761

**DIESEL
FUEL ONLY**











CAUTION

MAKE SURE COOLING SYSTEM
IS PROPERLY FILLED BEFORE
STARTING ENGINE

DO NOT REMOVE CAP
WHEN ENGINE IS HOT.
WAIT AT LEAST 15 MIN AFTER
STOPPING ENGINE BEFORE
CAREFULLY REMOVING CAP.

KEEP HANDS
AWAY FROM
MOVING PARTS

	BT-8W31C		
SN	RNT27BJJ26680		
COM#	1003913		
KW	VOLTAGE	120/240	
PHASE	1	AMPS	66/33
HERTZ	60	POWER FACTOR	1.0
RPM	1800	INSULATION CLASS	F
DUTY	CONT.	AMBIENT	40. C
FUEL	ULTRA LOW SULFUR DIESEL ONLY		
PERKINS GENERATORS		0002200 11 2010	
PERKINSGENERATORS.COM		1-800-749-6027	
MADE IN THE U.S.A. BT-8W31C SEE USER MANUAL FOR DETAILS			

WARNING

Readability, these signs are not intended to be replaced by any other signs or labels. It is the responsibility of the user to ensure that all signs and labels are clearly visible and legible. If you are unable to read any of the signs or labels, please contact the manufacturer for more information. Do not use the signs or labels if they are damaged or illegible. Do not use the signs or labels if they are missing or faded.

SUSPENSION UP DOWN

AIR RIDE

ON

AIR PUMP

1331.

WALVE DISCONNECT

Poljak

TRAILER

WALVE DISCONNECT

Poljak

INVERTER

13.14.

COMPRESSOR

TRAILER



TRAILER

HYDRASTAR

Waring International
Model 22-001
Watts 22 and 22-001 Series
Watts Water Pump
Made in the USA















TRAVEL
TRUCKS

DESTINGER

Power Built Trailers by
T&E ENT.
AutoHaulers
www.tandee.com

WESTINGER









WESTINGER





STINGER

WARNING
SAFETY
INSTRUCTIONS



STINGER



800-854-4856

PLEASE OPEN
WITH
KEYS
OR
NOTES
LEFT INSIDE





 **STINGER**  800-304-4880

AXE
EQUIPMENT
SALES & SERVICE
10000
10000








FRIEDRICH



- DO NOT OPERATE THIS EQUIPMENT WHILE ANY PART IS
IN CONTACT WITH A FLAME OR EXPLOSION, WHICH MAY RESULT IN
DEATH OR SERIOUS INJURY.
- FOR VEHICLE USE:
1. Do not ride in the vehicle storage area while
vehicle is present.
 2. Do not sleep in the vehicle storage area when
vehicles are present.
 3. Close doors and windows in order of separation
of mechanical arms, any cables in ground.
 4. High heat may be generated at stored vehicles after
starting and heat off the tank.
 5. Do not drink, eat, or use any other items
while using this vehicle.
 6. Turn the vehicle, including, in all conditions,
including, including for viewing the transmission
from when vehicle is present.
 7. Do not operate propane equipment, gas lights,
or other propane equipment when vehicles are
and present.







































Auto Haul Trailers by
TEENT
AutoHaulers

ESTINGER









ESTINGER

